

New Compactor sheet Fitting Instructions



1. Place compactor sheet on as normal. Fold up the yellow sheet and secure with bungee



2. Once container has been lifted onto the vehicle lower the yellow sheet.



3. Connect side long bungee to left door lock right bottom door hinge



4. Pull the lower bungee at either sides around wheel hubs



5. Connect sheet hooks to floor channels under the bin



6. Connect side short bungee handle to same points as number 3



Tipping Instructions

Before opening the door disconnect the yellow sheet and hooks, fold the sheet up. Once load is tipped lower bin and pull tight, leave in the upright position for next job.

© Simon Liddiard 2007

